

SCUBA

WATER EFFECT LIGHT WITH 90W LED,
COLOUR WHEEL AND 2 LENSES - DMX CONTROL TABLE



5 Channel Mode					
Ch.	Function	Values and Description			
1	Dimmer	000	-	255	0% to 100%
2	Multifunctional Strobe	000	-	005	Strobe Open
		006	-	010	Strobe Closed
		011	-	033	Pulse, Slow -> Fast
		034	-	056	Ramp up, Slow -> Fast
		057	-	079	Ramp down, Slow -> Fast
		080	-	102	Random Strobe Effect, Slow -> Fast
		103	-	127	Strobe Break Effect, 5s.....1s (Short burst with break)
		128	-	250	Strobe Slow -> Fast <1Hz - 20Hz
		251	-	255	Strobe Open
		3	Colour Wheel	000	-
006	-			012	Split Colour Open - Red
013	-			019	Red
020	-			026	Split Colour Red - Orange
027	-			033	Orange
034	-			040	Split Colour Orange - Yellow
041	-			047	Yellow
048	-			054	Split Colour Yellow - Green
055	-			061	Green
062	-			068	Split Colour Green - Cyan
069	-			075	Cyan
076	-			082	Split Colour Cyan - Lavender
083	-			089	Lavender
090	-			096	Split Colour Lavender - Magenta
097	-			103	Magenta
104	-			110	Split Colour Magenta - Open
111	-			125	Colour Off (open)
126	-			128	Colour Wheel Rotation Stop
129	-	255	Colour Wheel Rotation Slow -> Fast		
4	Effect Wheel 1	000	-	000	Effect Wheel Rotation Off
		001	-	127	Effect Wheel Rotation, Slow -> Fast, CCW
		128	-	255	Effect Wheel Rotation, Fast -> Slow, CW
5	Effect Wheel 2	000	-	000	Effect Wheel Rotation Off
		001	-	127	Effect Wheel Rotation, Slow -> Fast, CCW
		128	-	255	Effect Wheel Rotation, Fast -> Slow, CW











